



Automatic SplitJaw Tester



Product Resources

[61-096 Split-Jaw™
Smart Meter
Instructions](#)

(PDF | 3510K | Rev 4)

[61-096 Split-Jaw™
Smart Meter Manual](#)

(PDF | 398K | Rev 2)

Features

Automatically senses and displays AC/DC Volts, AC Amps,
resistance and continuity
Measures 0-200AAC
Measures 0-750 VAC
Measures 0-1000 VDC
Measures 0-2000 Ohms
Audible Continuity
Data Hold
Integral Lead Storage
Replaceable test leads
Auto power off
Low battery indication
CAT IV - 600V
CAT III - 1000V

Models

Description	Catalog #
Automatic SplitJaw Tester	61-096